

# Návod na nastavení hloubky vybití baterie-Solax

The screenshot shows the Solax Power web interface. On the left is a dark sidebar with navigation icons for 'Agenti', 'Uživatelé', 'Systém a web', 'Zařízení', 'Správa výstrah', 'Správa zařízení', 'Nová zařízení', 'Nastavení ovladače', 'Řízení zásob', 'Statistika statistiky', and 'Systémová nastavení'. The main content area has a top navigation bar with 'Název instalace', 'Přihlášení účtů', 'Systémová velikost (kW)', 'Online komunikace', and 'Obsluhovat'. Below this is a table with columns for 'Název instalace', 'Přihlášení do účtu', 'Systémová velikost (kW)', 'Online komunikace', and 'Obsluhovat'. The first row contains the value 'Keyf' in the 'Název instalace' column, which is highlighted with a red box. Below the table is a pagination control showing 'Celkem 47', '10 na stranu', and page numbers 1 through 5, with '1' selected.

This screenshot shows a detailed view of the 'Keyf' installation. At the top, there are three tabs: 'Analýza stránky', 'Měřicí zařízení', and 'Statistická zpráva'. The 'Měřicí zařízení' tab is active and highlighted with a red box. Below the tabs, the name of the installation is 'Keyf'. Underneath, there is a diagram showing a hierarchy: 'Keyf' at the top, connected to 'WIFI3.0', which is connected to a device with the ID '735085'. The '735085' ID is highlighted with a red box. At the bottom right, there is a text label 'Monitorovací interval obnovení dat, 5 min'.

